

1	ECOLINE® ADH fleeceback single ply membrane single ply membrane fully bonded using ADH adhesive
2	ADH Adhesive
3	HYTHERM® tapered / flat board insulation fully bonded using Hyra-Stik adhesive (thickness to achieve design U-value and/or design fall)
4	ECOLINE® tubular washer and mechanical fastener (C) fixing
5	Heat welded seam to field membrane
6	AXTER® universal leaf guard (to suit deign requirements)
7	Galvanised bent metal angle mechanically fixed at perimeter (by specialist subcontractor)
8	AXTER® rainwater outlet with PVC membrane flange
9	Vernis Antac ST Primer
10	ECOLINE® air & vapour control layer (AVCL)
11	Plywood roof deck by specialist contractor

